

REBOTE DELAY

Rev.1.May.5.2002

Build the Princeton tech digital delay, from the application sheet adapted for stompbox use which includes a 5v positive voltage regulator and a FET input booster. Off board components except for the potentiometers are not shown on the layout. Trademarks are property of their owners.



LAYOUT



READY TO TRANSFER

Parts List

Resistors

1 - 5M1
2 - 100k
1 - 18k
2 - 15k
4 - 10k
1 - 6k8
1 - 5k6
1 - 4k7
1 - 2k4

Capacitors

1 - 100 µF
2 - 47 µF
2 - 10 µF
2 - 4.7 µF
3 - 0.1µF
2 - 0.082 µF
1 - 3900pF
1 - 3300pF
2 - 560pF

IC's

IC1 - PT2399
IC2 - 5v Reg


Transistors

Q1 - 2N5457

Pots

1 - 50k lin.
1 - 50k log.

Schematic



Layout and presentation by Francisco Peña 2001 2002®.
All rights reserved. Authorization for personal use only.
any commercial use is forbidden.
Permission for posting/serving limited to
http://www.tonepad.com
Permission refused for posting from other sites.