



SW4	SW3	SW2	SW1	NAME	DESCRIPTION
ON	OFF	OFF	ON	HALL 1	BRIGHT HALL REVERB FOR DRUMS, GUITARS, AND VOCALS.
ON	ON	OFF	ON	HALL 2	WARM HALL FOR ACOUSTIC GUITARS, PIANOS, AND VOCALS.
OFF	ON	OFF	ON	ROOM 1	HARDWOOD STUDIO FOR ACOUSTIC INSTRUMENTS.
OFF	OFF	OFF	ON	ROOM 2	AMBIENCE FOR ACOUSTIC MIXES AND SYNTH SOUNDS.
OFF	OFF	OFF	OFF	ROOM 3	WARM ROOM FOR GUITARS AND RHYTHM INSTRUMENTS.
OFF	ON	OFF	OFF	PLATE 1	CLASSIC PLATE REVERB FOR LEAD VOCALS AND INSTRUMENTS.
OFF	ON	ON	OFF	PLATE 2	SIZZLING BRIGHT PLATE REVERB FOR VOCALS AND DRUMS.
OFF	OFF	ON	OFF	PLATE 3	SHORT VINTAGE PLATE REVERB FOR SNARES AND GUITARS.
OFF	OFF	ON	ON	CHORUS	STEREO CHORUS FOR GUITARS AND PIANOS.
OFF	ON	ON	ON	FLANGE	STEREO FLANGER FOR JET WASH EFFECTS.
ON	ON	ON	ON	DELAY 1	125MS SLAPBACK DELAY FOR VOCALS AND GUITARS.
ON	OFF	ON	ON	DELAY 2	190MS DELAY FOR PERCUSSIVE ARPEGGIOS.
ON	OFF	ON	OFF	CHORUS/ROOM 1	CHORUS WITH REVERB FOR GUITARS, SYNTHS, AND PIANOS.
ON	ON	ON	OFF	CHORUS/ROOM 2	AUTO-WAH GUITAR EFFECT WITH REVERB FOR LEAD INSTRUMENTS.
ON	ON	OFF	OFF	VOCAL CANCEL	REMOVES LEAD VOCALS FROM MANY STEREO RECORDINGS.
ON	OFF	OFF	OFF	ROTARY SPEAKER	ROTARY SPEAKER EMULATION FOR ORGANS AND GUITARS.